

FASHION MASTER 2.0

The Miele steam ironing system



Made in
Germany

Miele FashionMaster 2.0

Perfect results. Miele quality.





Washing, drying, ironing – forever better with Miele. Those who place the highest of demands on their appliances in terms of quality and perfection know this.

With the FashionMaster steam ironing system, Miele is demonstrating this once again. After your laundry has been gently washed in a Miele washing machine and gently dried in a Miele tumble dryer, the FashionMaster ensures perfect ironing results. The steam ironing system provides first-class quality and unique user convenience.

Allow yourself to be inspired with an appliance which has been carefully thought-out right down to the very last detail.



Innovation for perfect results and convenience.



Highlights

Exclusive to Miele Unique – the honeycomb soleplate

The honeycomb structure has already proven effective on Miele washing machine and dryer honeycomb drums and now also makes a difference on the Miele FashionMaster. With the patented honeycomb soleplate¹⁾ you can achieve excellent results every time. Unlike conventional hand irons, steam is distributed perfectly and evenly along a network of channels across the entire soleplate. This allows the iron to glide effortlessly and gently over textiles.



Exclusive to Miele 1-2-Lift System

Two easy steps to set up, requiring little or no effort at all! With the 1-2-Lift-System, the entire appliance can be easily set up. Unfolding and folding away again is easy thanks to the patented²⁾ X-frame mechanism.



Smooth height adjustment

A built-in pneumatic stay allows the table to be adjusted smoothly to suit individual preferences. The working heights are infinitely adjustable between 83 cm and 102 cm.

¹⁾ Europa-Patent EP 2 233 632 B1

²⁾ Europa-Patent EP 2 169 108 B1

Qualities unsurpassed.



User convenience

All-in-one concept

When the FashionMaster is folded together, only its elegant and timeless design catches your eye. Thanks to discreet and sophisticated storage compartments, all accessories disappear into the compact tower. Even the hand iron is securely tidied away yet easily accessible.





Large ironing table with Comfort Zone

With a 120 x 40 cm large ironing table, even entire trouser legs or large shirts fit on the FashionMaster. The Comfort Zone at the narrow end of the ironing table is designed for you to iron the entire front of a blouse or shirt.



Exclusive to Miele Automatic descaling

Descaling now or later? One less matter to worry about. The FashionMaster takes care of it! The water hardness has to be keyed in once and a Miele descaling tablet added if required. The LED on the Miele FashionMaster informs you when descaling is required.



Automatic rinsing

Mineral residue left behind by the evaporation process must be removed by rinsing the steam generator to ensure consistent appliance performance. The FashionMaster calculates rinse intervals automatically based on the volume of water evaporated. Water from the rinse process is collected in an integrated residual water container.



Mobility and secure stand

The FashionMaster stands firmly without requiring additional support even when folded together, and can be positioned anywhere in your home. The wheels, with their supple tread, allow the appliance to be transported easily - carpets, door sills or even odd steps can be negotiated with ease.

Achieve seamless results with ease.

Ironing results

Exclusive to Miele **Innovation of the Steam Jet**



The Steam Jet allows wrinkles to be removed from hanging garments simply and quickly. The Steam Jet only weighs half as much as the hand iron but uses the same steam pressure and steam output. It also prevents shiny patches on textiles. The Steam Jet can also be used when the FashionMaster is folded away.



Steam delivery plays a key role

With the FashionMaster, you can achieve professional ironing results thanks to 4 bar steam pressure and a consistent output of 100 g/min. The steam penetrates even thick material and reduces ironing times. Steam pulses or continuous steam delivery - you can select the most suitable option using the steam button on the hand iron.



Non-stick soleplate for difficult items

Sequins, prints or extremely delicate fabrics – with the Miele FashionMaster you can handle any type of challenge. The clip-on non-stick soleplate for extra gentle treatment prevents shiny patches on dark garments and is also suitable for items with detailed adornment. There is no need to iron items inside out.



Perfect creases

A crease down the centre of a trouser leg can be ironed fast and perfectly with the Miele FashionMaster.



Active ironing table

The ironing table is equipped with a fan for easy ironing. It is also 'intelligent' as a built-in automatic switch-on and switch-off function starts the fan as soon as the steam button on the hand iron is pressed, and in the event of a short break during ironing, steam supply is automatically switched off after a short run-on time. The Memory function registers if you have used steam extraction or inflation during ironing. This activates the function the next time steam is required. A touch of a button directly on the hand iron allows you to switch conveniently between the two functions. The power setting is also easily adjustable to suit the textile.



Suction function with three benefits

Optimum steam penetration without condensation - the built-in suction function ensures steam penetration of garments and prevents build-up of condensation on the ironing table. This is of particular advantage when ironing multi-layered garments. Items on the ironing table are also automatically held securely in place by the suction function during ironing.



Inflation function - air cushion for particularly gentle fabric care

The FashionMaster ironing table features an inflation function for items which need to be smoothed but should not be pressed. The fan creates an air cushion between the item being ironed and the table - perfect for ironing delicate garments such as silk blouses with frills, cashmere jumpers, etc. This function also prevents seam and hem impressions on lower layers of garments.

Fast and safe ironing

Saving time and safe use



Fast ironing of multi-layered garments

Save physical strength and time! With the FashionMaster, multi-layered and dense textiles now only need to be ironed on one side, not on both. The large quantity of steam and high steam pressure applied can penetrate even thick, dense material such as denims. This makes ironing on both sides unnecessary.



The 1.25 l water container – easy and uncomplicated to handle

The water container of the FashionMaster can be simply removed and refilled with tap water during the ironing process. The user-friendly flat design of the water tank allows refilling even under low taps.



CoolDown function

Safety is always high on the design agenda at Miele. Movement sensors and button monitoring ensure that the hand iron switches off automatically after it has not been used for approximately 3 minutes. As soon as movement is detected, the appliance switches on again.



Auto-Off function for peace of mind

When the hand iron or Steam Jet is not used for approx. 15 minutes, the entire appliance switches off automatically. There is no need to worry if you have forgotten to switch the iron off.



Simply perfect laundry care

When selecting your Miele laundry appliance, you have chosen the best in quality and performance. To constantly achieve optimum results it is also important to use the right laundry detergents. For this reason Miele offers laundry care products specifically suited to Miele appliances. The Miele laundry care products are sold separately and can be conveniently purchased at www.mieleshop.com.au

FashionMaster 2.0

Product overview



Model/Sales designation	B 2826
Intelligent ironing	
Honeycomb soleplate	●
Automatic fan switch-on/switch-off	●
Fan Memory function	●
Power levels - fan	2
Time-saving ironing	
Water container volume in l	1.25
Removable water container	●
Water container - refillable any time	●
Ironing multi-layered items	●
Perfect ironing results	
Steam pressure in bar	4
Steam output in g/min	100
Vertical steam	●
Steam starting from temperature level	2
Steam Jet	●
Suction and inflation function	● / ●
Separate non-stick soleplate	●
Excellent user convenience	
All-in-one	●
1-2-Lift System	●
Infinitely variable height adjustment with gas pressure stay (cm)	83-102
Castors gentle on the floor	●
Ironing table with Comfort Zone	●
Automatic descaling	●
Automatic rinsing	●
Storage compartment for iron	●
Storage compartment for connection cable and accessories	●
Safety	
CoolDown function	●
Auto-Off function	●
Dimensions and consumption	
H x W x D (cm)	96.3 x 146 x 47.1
H x W x D (cm), folded	128.1 x 38.2 x 47.1
Ironing surface area (cm)	120 x 40
Rated load (kW)	2.2



Miele Australia Pty. Ltd.
 ACN 005 635 398
 ABN 96 005 635 398

Miele Australia Pty. Ltd.
 Head Office
 1 Gilbert Park Drive
 Knoxfield VIC 3180

Telephone 1300 4 MIELE (1300 464 353)

Miele Center Knoxfield
 1 Gilbert Park Drive
 Knoxfield VIC 3180

Miele Center South Melbourne
 206-210 Coventry Street
 South Melbourne VIC 3205

Miele Center and Office Sydney
 3 Skyline Place
 Frenchs Forest NSW 2086

Miele Center and Office Brisbane
 39 Harvey Street North
 Eagle Farm QLD 4009

Miele Center and Office Adelaide
 83 Sir Donald Bradman Drive
 Hilton SA 5033

Miele Center and Office Perth
 205-207 Stirling Highway
 Claremont WA 6010

www.miele.com.au

Miele New Zealand Limited
 IRD 98 463 631

Miele Center
 8 College Hill
 Freemans Bay, Auckland 1011

Telephone 0800 4 MIELE (0800 464 353)

www.miele.co.nz

Miele Global Headquarters
 Miele & Cie. KG
 Carl-Miele Strasse 29
 D-33332 Gütersloh
 Federal Republic of Germany

Foreign Sales Companies

(A)	Miele Ges.m.b.H., Wals/Salzburg
(AUS)	Miele Australia Pty. Ltd., Melbourne
(B)	N.V. Miele S.A., Mollem
(CDN)	Miele Limited, Vaughan/Ontario
(CH)	Miele AG, Spreitenbach
(CL)	Miele Electrodomésticos, Santiago de Chile
(CN)	Miele Shanghai Trading Ltd., Shanghai
(CZ)	Miele spol.s.r.o., Brno
(D)	Miele & Cie. KG, Gütersloh
(DK)	Miele A/S, Glostrup/Copenhagen
(E)	Miele S.A., Alcobendas/Madrid
(EST)	Miele SIA Eesti filiaal, Tallinn
(F)	Miele S.A.S., Le Blanc-Mesnil/Paris
(FIN)	Miele Oy, Vantaa/Helsinki
(GB)	Miele Company Ltd., Abingdon
(GR)	Miele Hellas E.P.E., Psychiko-Athens
(H)	Miele Kft., Budapest
(HK)	Miele Hong Kong Ltd., Hong Kong
(HR)	Miele d.o.o., Zagreb
(I)	Miele Italia S.R.L., Eppan
(IND)	Miele India Pvt Ltd., New Delhi
(IRL)	Miele Ireland Ltd., Dublin
(J)	Miele Japan Corp., Meguro-ku/Tokyo
(KZ)	Miele Liability Partnership, Almaty
(L)	Miele s.à r.l., Luxembourg
(LT)	SIA "Miele" Lietuvos filialas, Vilnius
(LV)	Miele SIA, Riga
(MAL)	Miele Sdn Bhd, Kuala Lumpur
(MEX)	Miele S.A. de C.V., Mexico City
(N)	Miele AS, Nesbru/Oslo
(NL)	Miele Nederland B.V., Vianen
(NZ)	Miele New Zealand Ltd., Auckland
(P)	Miele Portuguesa Lda., Carnaxide/Lisbon
(PL)	Miele Sp. z o. o., Warsaw
(RO)	Miele Appliances S.R.L., Otopeni
(ROK)	Miele Korea Ltd., Seoul
(RU)	000 Miele CIS, Moscow
(S)	Miele AB, Solna/Stockholm
(SGP)	Miele Pte. Ltd., Singapore
(SK)	Miele spol.s.r.o., Bratislava
(SLO)	Miele d.o.o., Ljubljana
(SRB)	Miele d.o.o., Belgrade
(TR)	Miele Elektrikli Aletier, Levent/Istanbul
(UA)	Miele LLC, Kiev
(UAE)	Miele Appliances Ltd., Dubai
(USA)	Miele, Inc., Princeton/New Jersey
(ZA)	Miele (PTY) Ltd., Bryanston/Johannesburg



www.mieleshop.com.au